



XP-8000-CE6

User Manual

(for WinCE 6.0 Based XPAC)

V1.0.6, December 2025



XP-8031-CE6/XP-8131-CE6/ XP-8331-CE6/ XP-8731-CE6

Written by Sean Hsu

Edited by Anna Huang

Warranty

All products manufactured by ICP DAS are under warranty regarding defective materials for a period of one year, beginning from the date of delivery to the original purchaser.

Warning

ICP DAS assumes no liability for any damage resulting from the use of this product. ICP DAS reserves the right to change this manual at any time without notice. The information furnished by ICP DAS is believed to be accurate and reliable. However, no responsibility is assumed by ICP DAS for its use, not for any infringements of patents or other rights of third parties resulting from its use.

Copyright

Copyright © 2018 by ICP DAS Co., Ltd. All rights are reserved.

Trademark

The names used for identification only may be registered trademarks of their respective companies.

Contact US

If you have any problem, please feel free to contact us.

You can count on us for quick response.

Email: service@icpdas.com

Contents

1. INTRODUCTION	6
1.1. Features.....	7
1.2. Specifications	8
1.3. Overview	10
1.4. Dimensions.....	17
1.5. Download Center	20
2. GETTING STARTED.....	21
2.1.1. Mounting the XP-8000-CE6	22
2.1.2. Deploying a Basic XP-8000-CE6 System.....	25
2.1.3. Inserting the I/O Modules	27
2.1.4. Powering up the XP-8000-CE6.....	29
2.2. Configuring the Boot Mode.....	33
2.3. Changing the User Interface Language	35
2.4. Using XPAC Utility to Manage the XP-8000.....	37
2.5. Using Remote Display to Control the XP-8000-CE6 Remotely	38
2.6. Using DCON Utility Pro Configure I/O Modules	40
2.7. Using DCON_CE to Remote Configure the I/O Module.....	43
3. TOOLS AND TASKS.....	47
3.1. XPAC Utility.....	48
3.1.1. Menu Bar – File.....	49
3.1.2. Menu Bar – Help.....	50
3.1.3. Property Tab - General.....	51
3.1.4. Property Tab – General2.....	53
3.1.5. Property Tab – Display.....	54
3.1.6. Property Tab – IP Config	55
3.1.7. Property Tab – Network.....	56
3.1.8. Property Tab – Device Information.....	59
3.1.9. Property Tab – Auto Execution	60
3.1.10. Property Tab – Rotary Execution	61
3.1.11. Property Tab – Multi-IO Modules	62
3.2. DCON Utility Pro.....	63
3.3. DCON_CE.....	64
3.4. TaskMgr	65
3.5. VCEP	66
3.6. Remote_Display	67
3.7. SendToCOM.....	68

3.8.	RegEdit	69
3.9.	ISQLW35	70
3.10.	INotepad.....	71
4.	YOUR FIRST XP-8000-CE6 PROGRAM	72
4.1.	Setting up the Development Environment.....	72
4.1.1.	Preparing the Development Tools	73
4.1.2.	Installing the XP-8000-CE6 SDK	74
4.2.	First XP-8000-CE6 Program in VB.NET.....	75
4.2.1.	Create a new project	76
4.2.2.	Specify the path of the PAC reference.....	79
4.2.3.	Add the control to the form	81
4.2.4.	Add the event handling for the control	83
4.2.5.	Upload the application to XP-8000-CE6	84
4.2.6.	Execute the application on XP-8000-CE6	86
4.3.	First XP-8000-CE6 Program in Visual C#.....	87
4.3.1.	Create a new project	88
4.3.2.	Specify the path of the PAC reference.....	91
4.3.3.	Add the control to the form	93
4.3.4.	Add the event handling for the control	95
4.3.5.	Upload the application to XP-8000-CE6	96
4.3.6.	Execute the application on XP-8000-CE6	98
4.4.	First XP-8000-CE6 Program in Visual C++	99
4.4.1.	Create a new project	100
4.4.2.	Configure the Platform	105
4.4.3.	Specify the Libraries of the PAC SDK.....	106
4.4.4.	Add the control to the form	108
4.4.5.	Add the event handling for the control	111
4.4.6.	Upload the application to XP-8000-CE6	113
4.4.7.	Execute the application on XP-8000-CE6	115
5.	I/O EXPANSION MODULES AND SDKS SELECTION	116
6.	APIS AND DEMO REFERENCES	120
6.1.	PAC Standard APIs for System Operation.....	121
6.1.1.	VB.NET Demos for PAC Standard APIs.....	122
6.1.2.	C# Demos for PAC Standard APIs.....	123
6.1.3.	Visual C++ Demos for PAC Standard APIs	124
6.2.	PAC Standard APIs for PAC Expansion I/O	125
6.2.1.	VB.net Demos for PAC Expansion I/O	126
6.2.2.	C# Demos for PAC Expansion I/O.....	128

6.2.3.	Visual C++ Demos for PAC Expansion I/O	130
7.	RECOVERY AND RESTORE	132
7.1.	Recovering the XP-8000-CE6	133
7.2.	Restoring the Rescue CF Card or USB Disk	137
8.	XP-8000-CE6 UPDATES	141
8.1.	OS updates	142
8.1.1.	OS Updates from file	143
8.1.2.	OS Updates using the Rescue CF Card or USB disk.....	145
8.2.	SDK Updates	146
8.2.1.	SDK Updates for VB.NET or C#	146
8.2.2.	SDK Updates for VB.NET or Visual C++	148
9.	APPLICATION OF RS-485 NETWORK	150
9.1.	Basic RS-485 Network	151
9.2.	Daisy Chain RS-485 Network	152
9.3.	Star Type RS-485 Network.....	153
9.4.	Random RS-485 Network	155
9.5.	Master/Slave Settings	156
9.5.1.	XPAC as a Master (Default)	157
9.5.2.	XPAC as a Slave	159
TIPS – HOW TO.....		161
A.	How to Use the Printer	162
A.1.	How to Use a Network Printer	163
A.2.	How to Use a USB printer	165
B.	How to Online Debug the XP-8000-CE6 Program.....	166
C.	How to Automatically Synchronize XP-8000-CE6 Clock with an Internet Time Server	172
D.	How to Control the User Account Control in XP-8000-CE6	174
D.1.	How to Create a User Account.....	174
D.2.	How to Telnet to Remote Login the XP-8000-CE6 from PC.....	176
D.3.	How to Remove a User Account from the Login List	178
E.	How to use PACSDK library to program the XP-8000-CE6	180
E.1.	How to Read the XPAC Mode with PACSDK library	180
E.2.	How to Read the Module ID with XPAC API	181
E.3.	How to Use the Multi-IO Module with XPAC API.....	182
F.	How to update software from XP-8x4x-CE6 or XP-8000-Atom-CE6 to XP-8x3x-CE6.....	184
G.	How to Change the Battery	185
H.	I-8K and I-87K Modules	188
I.	Revision History	189

1. Introduction



XP-8000-CE6 Series is the new generation Windows CE 6.0 based PACs of ICP DAS. It is equipped with a x86 CPU (1 GHz) dual-core, various connectivity (VGA, USB, Ethernet, RS-232/485) and 0/1/3/7 I/O slot(s) for high performance parallel I/O modules (high profile I-8K Series) and serial I/O modules (high profile I-87K series). The benefits of running Windows CE 6.0 on XPAC include hard real-time capability, small core size, fast boot speed, interrupt handling at a deeper level and achievable deterministic control. XPAC is also capable of running PC-based control software such as Visual Basic .NET, Visual C#,.... etc. It has all of the best features of both traditional PLCs and Windows capable PCs.

For software copy protection, programmers can design software based on the 64-bit hardware serial number for making software copy protected.

1.1. Features

The XP-8000-CE6 offers the most comprehensive configuration to meet specific application requirements. The following list shows the hardware and software features designed to simplify installation, configuration and application.

Hardware Features

- Powerful CPU module: x86 CPU (1 GHz) dual core
- Rich Memories:
 - System Memory: 2 GB DDR3
 - Built-in Flash Disk: 32 GB
 - EEPROM: 16 KB
 - SRAM/MRAM: 512 KB
- VGA Port x 1, USB 2.0 port x 4, Serial port (RS-232/RS-485) x 5
- 64-bit Hardware Serial Number
- Dual Watchdog Timers
- Dual Ethernet Ports (10 M/100 M/1000 M)
- Redundant Power Input
- Operating Temperature: -25 to +75 °C

Software Features

- Windows Compact Edition 6.0
- ASP
- SQL Compact Edition 3.5
- .NET Compact Framework 3.5
- Remote Display
- Built-in OPC Server (Quicker)
- Rich Software Solution – SDK for Microsoft Visual Studio 2005/2008

1.2. Specifications

The table below summarizes the specifications of the XP-8000-CE6.


Models	XP-8031-CE6	XP-8131-CE6	XP-8331-CE6	XP-8731-CE6
Software				
OS	Windows CE 6.0			
.Net Compact Framework	3.5			
Embedded Service	FTP Server, ASP (Java Script, VB Script), SQL Compact Edition 3.5			
SDK Provided	DII for Visual Studio .Net 2005/2008			
Multilanguage Support	English, German, French, Spanish, Russian, Italian, Czech, Japanese, Korean, Simplified Chinese, Traditional Chinese			
CPU Module				
CPU	x86 CPU, 1 GHz, dual-core			
SDRAM	2 GB DDR3			
MRAM , Non-volatile Memory	512 KB (Retain memory without battery support)			
Flash	32 GB			
EEPROM	16 KB			
CF Card	CF slot, optional CF Card (supports up to 32 GB)			
RTC (Real Time Clock)	Provide second, minute, hour, date, day of week, month, year			
64-bit Hardware Serial Number	Yes, for software copy protection			
Dual Watchdog Timers	Yes (0.8 second)			
Rotary Switch	Yes (0 to 9)			
DIP Switch	-	Yes (8 bits)		
Programmable LED Indicator	2 (L1 and L2)			
VGA & Communication Ports				
VGA Resolution	1400x1050, 1024 x 768, 800 x 600 , 640 x 480			
Dual Ethernet Port	RJ-45 x 2, 10/100/1000 Base-T (Auto-negotiating, Auto MDI/MDI-X, LED indicators)			
USB 2.0	4			
COM 1	RS-232 (RxD, TxD and GND); 3000 V _{DC} isolated	Internal communication with high profile I-87K series modules in slots		

COM 2	RS-232 (RxD, TxD and GND); 3000 V _{DC} isolated			
COM 3	RS-485 (Data+, Data-); 3000 V _{DC} isolated			
COM 4	RS-232/RS-485 (RxD, TxD, CTS, RTS and GND for RS-232, Data+ and Data- for RS-485); 3000 V _{DC} isolated			
COM 5	RS-232 (RxD, TxD, CTS, RTS, DSR, DTR, CD, RI and GND); non-isolated			
I/O Expansion Slots				
Number of I/O slots	0	1	3	7
Supported I/O modules	I-8K and I-87K series I/O Modules			
Mechanical				
Dimensions (W x L x H), unit: mm	137 x 132 x 125	169 x 132 x 125	231 x 132 x 125	355 x 132 x 125
Installation	DIN-Rail or Wall Mounting			
Environmental				
Operating Temperature	-25 °C to +75 °C			
Storage Temperature	-30 °C to + 80 °C			
Ambient Relative Humidity	10 % to 90 % RH (non-condensing)			
Power				
Input Range	+10 V _{DC} to +30 V _{DC}			
Redundant Power Inputs	Yes, with one power relay (1 A @ 24 V _{DC}) for alarm			
Isolation	1 kV			
Capacity	2.2 A, 5 V supply to CPU and backplane, 20W in total	3.7 A, 5 V supply to CPU and backplane, 1.3 A, 5 V supply to I/O expansion slots, 25 W in total	3.8 A, 5 V supply to CPU and backplane, 3.2 A, 5 V supply to I/O expansion slots, 30 W in total	4.0 A, 5 V supply to CPU and backplane, 3.0 A, 5 V supply to I/O expansion slots, 35 W in total
Consumption	12W (0.5 A @ 24 VDC)	16.6 W (0.69 A @ 24 VDC)	16.8 W (0.7 A @ 24 VDC)	18 W (0.75 A @ 24 VDC)


1.3. Overview

The XP-8000-CE6 is equipped with several interfaces and peripherals that can be integrated with external systems. Here is an overview of the components and its descriptions.


XP-8031-CE6




XP-8131-CE6



XP-8331-CE6




XP-8731-CE6



The details of these items are as follows:


LED Indicators

The XP-8000-CE6 has 4 LED indicators. The first is labeled PWR, located near the power switch and shows the power status. The three other are located next the rotary switch, the left one is labeled RUN and shows the operation status, the two other are denoted L1 and L2 and used for user defined.



LED Indicator	Label	State (Color)	Meaning
Programmable LED Indicators	L1 and L2	-	Programmable LED indicators
System LED indicator	RUN	Orange	OS is running
Power LED Indicator	PWR	Green	Power 1 is on


Operating mode Selector



Rotary Switch is an operating mode selector. The XP-8000-CE6 has several operating modes, for more detailed information about these operating modes, please refer to “2.2 Configuring the Boot Mode”


Power Switch

The power switch is a small switch that enables or disables power to electric circuits and loads in the XP-8000-CE6.



Redundant Power (PWR1 and PWR2) and relay output

The XP-8000-CE6 has a 2-row 10-wire terminal block; there has 4-wire for redundant power inputs and 2-wire for relay output. The details of the redundant power are shown to the side.




- **Redundant Power**

The XP-8000-CE6 provides redundant power that can keep the device running if a problem occurs in the power supply.

- **Relay Output**

The XP-8000-CE6 has a relay output that can be used to control a light, siren, or other low voltage device when an alarm occurs.



Communication Ports

The XP-8000-CE6 is equipped with several interfaces and peripherals that can be integrated with external systems.

- **CF slot**

The CF slot supports system recovery using a CF card; optional CF card available.

Tips & Warnings




The XP-8000-CE6 Doesn't Support Hot Swap.

The XP-8000-CE6 does not support hot swapping of CF cards, you need to shut down the XP-8000-CE6 before you insert the CF card.

● VGA Port

The VGA connector is a 3-row 15-pin connector that can be used to connect a monitor at a variety of supported VGA resolutions. and the output resolution covers, 800 x 600, 1024 x 768 and 1400 x 1050.



● Ethernet Ports (LAN1 and LAN2)

The XP-8000-CE6 has 2 Ethernet ports that can be used to connect the router to the Internet or to other devices.

Each Ethernet port has 2 LED indicators, which are used to indicate the network speed and Link/Acting, as described below.



LED Indicator	State (Color)	Meaning
1G	ON (Yellow)	Network Speed: 1 GB
	OFF	Network Speed: 10/100 MB
Link/Act	ON (Green)	The Link is active
	OFF	The Link is inactive
	Blinking(Green)	Network activity

● USB Ports (P1, P2, P3 and P4)

The XP-8000-CE6 has 4 USB 2.0 ports that can be used to connect the USB devices such as mouse, keyboard or an external USB hard drive.

● COM1 (RS-232) (for XP-8031-CE6 only)

The COM1 port is a 9-pins RS-232 connector. The details of the COM1 port specifications are shown to the side.

Port Type: Male


Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 5, 6, 7, 8

Parity: None, Even, Odd, Mark (Always 1), Space (Always 0)

Stop Bits: 1, 2

FIFO: 128 bytes



● COM2 (RS-232)

The COM2 port is a 9-pins RS-232 connector. The details of the COM2 port specifications are shown to the side.

Port Type: Female


Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 7, 8

Parity: None, Even, Odd

Stop Bits: 1

FIFO: 1 byte



● COM3 (2-wire RS-485)

Port Type: Terminals


Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 5, 6, 7, 8

Parity: None, Even, Odd, Mark (Always 1), Space (Always 0)

Stop Bits: 1, 2

FIFO: 128 bytes



● COM4 (RS-232/RS-485)


The COM4 port is a 9-pins RS-232/RS-485 connector. The details of the COM4 port specifications are shown to the side.

Port Type: Male

Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 5, 6, 7, 8

Parity: None, Even, Odd, Mark (Always 1), Space (Always 0)



COM4 can be configured as either RS-232 or RS-485, that only can select configuration depends on the pin connections as follows:

- **RS-232** (RXD, TXD, CTS, RTS and GND)
- **RS-485** (Data+ and Data-)

There is no software configuration or hardware jumper needed.

● COM5 (RS-232)

The COM5 port is a 9-pins RS-232 connector. The details of the COM5 port specifications are shown to the side.

Port Type: Male


Baud Rate: 115200, 57600, 38400, 19200, 9600, 4800, 2400, 1200 bps

Data Bits: 5, 6, 7, 8

Parity: None, Even, Odd, Mark (Always 1), Space (Always 0)

Stop Bits: 1, 2

FIFO: 16 bytes



Tips & Warnings

1. All COM ports of XP-8000-CE6 don't support Mark and Space parity settings.



2. The table below shows the data bit and their corresponding stop bit for COM2, COM3 COM4, and COM5

Word Length	Number of Stop Bits
5, 6, 7, 8	1
5	1.5
6, 7, 8	2


1.4. Dimensions

The diagrams below provide the dimensions of the XP-8000-CE6 to use in defining your enclosure specifications. Remember to leave room for potential expansion if you are using other components in your system.

The height dimension is the same for all XP-8000-CE6. The width depending on your choose of I/O expansion slots. All dimensions are in millimeters.


XP-8031-CE6/XP-8131-CE6/XP-8331-CE6/XP-8731-CE6

Left Side View




XP-8031-CE6

Front View




XP-8131-CE6

Front View




XP-8331-CE6

Front View



Front View



1.5. Download Center

The XP-8000-CE6 Download Center can be accessed by clicking the corresponding icon on the product page. This center centralizes all technical documents, software utilities, and certification data required for the product series.

HOME > PRODUCTS > PACs > WinCE PACs > XP-8000-CE6 > XP-8000-CE6 Series

XP-8000-CE6 Series

Standard PAC with x86 CPU and WinCE 6.0

Catalog

Download Center

Data Sheet

FAQ



Features

- x86 CPU, 1.0 GHz, dual-core
- Windows CE 6.0
- Hard Real-Time Capability
- Rich software support
- Various Memory and Storage options (1GB and 3GB)


Download Center

Download Center

Search for Subjects ▾

User Manual

FILE NAME	DESCRIPTION	MODEL	LAST UPDATE
VCEP	Quick Start Manual	XP-8000-CE6 Series	2025-10-21
PAC Standard API (WinCE Platform)	User Manual for WinCE PAC	XP-8000-CE6 Series	2025-01-10
XP-8000-CE6	User Manual	XP-8000-CE6 Series	2024-05-06

Quick Start

FILE NAME	DESCRIPTION	MODEL	LAST UPDATE
XP-8000-CE6	Quick Start	XP-8000-CE6 Series	2025-12-05

Utility & Tools

FILE NAME	DESCRIPTION	MODEL	LAST UPDATE
-----------	-------------	-------	-------------

2. Getting Started

This chapter provides a guided tour of the XP-8000-CE6 installation and configuration that describes the steps needed to download, install, configure, and run the basic procedures for user working with the XP-8000-CE6 for the first time.


Before starting any task, please check the package contents. If any of the following package contents are missing or damaged, contact your dealer, distributor.



XP-8000-CE6



Screw Driver (1C016) 2.4 mm



Quick Start Guide


2.1.1. Mounting the XP-8000-CE6

The XP-8000-CE6 can be mounted either directly to a wall/panel, or onto a standard 35mm DIN rail.

Wall/Panel mounting

Step 1: Install the four mounting screws into the 4 keyhole mounting holes


Step 2: Fasten the screws securely



Tips & Warnings




There must be a minimum clearance of 50mm between the XP-8000-CE6 and the top and bottom side of the enclosure panel.



DIN Rail mounting

Step 1: Hook upper tab over upper flange of DIN rail


Step 2: Tilt the module toward DIN rail until it snaps securely to DIN rail



Tips & Warnings



A good common ground reference (earth ground) is essential for proper operation of the XP-8000-CE6. One side of all control circuits, power circuits and the ground lead must be properly connected to earth ground by either installing a ground rod in close proximity to the enclosure or by connecting to the incoming power system ground. There must be a single-point ground (i.e. copper bus bar) for all devices in the enclosure that require an earth ground.



Connect the ground lead to the ground screw

2.1.2. Deploying a Basic XP-8000-CE6 System


The XP-8000-CE6 provides a variety of communication interface to suit a range of application. Here is a simple application for using the XP-8000-CE6.

Step 1: Connect the positive terminal (+) of the power supply to the terminal PWR1/2 and the negative terminal (-) of the power supply to the P.GND

Tips & Warnings




1. The input range of power supply is +10 to +30 V_{DC}.
2. The XP-8000-CE6 have two power inputs that can be connected simultaneously to the two independent power sources. If one power source fails, the other source takes over automatically. Redundant power inputs help assure non-stop operation of the XP-8000-CE6.



Step 2: Connect the USB mouse or the USB keyboard to the USB port

Step 3: Connect the monitor to the VGA port

Step 4: Connect to PC or the laptop to the LAN port via an Ethernet switch




2.1.3. Inserting the I/O Modules

XP-8000-CE6 has 0/1/3/7 I/O expansion slot(s) and only supports I-8K and I-87K series I/O modules.

Before choosing the right I/O modules, you first need to know the I/O expansion capacities in order to choose the best expansion module for achieving maximal efficiency. For more information about the I/O expansion modules that are compatible with the XP-8000-CE6, please refer to: http://www.icpdas.com/root/product/solutions/remote_io/rs-485/i-8k_i-87k/i-8k_i-87k_selection.html

Step 1: Align circuit card with slot and press firmly to seat module into connector




Tips & Warnings



It is recommended that the power to the XP-8000-CE6 is switched off when wiring the I/O module which are plugging in the XP-8000-CE6 slots.

Step 2: Pull top and bottom locking tabs toward module face. Click indicates lock is engaged




Step 3: Attach field wiring using the terminal block, and then insert the terminal block

All I/O Web Page include the I/O module specifications, pin assignments and wiring connections.

For example, Pin Assignments and Wiring connections for the I-87054W module are as follows:

http://www.icpdas.com/root/product/solutions/remote_io/rs-485/i-8k_i-87k/i-87054w.html




2.1.4. Powering up the XP-8000-CE6

The XP-8000-CE6 works with 24 VDC power and provides redundant power inputs with two terminal blocks for PWR1 and PWR2 input.

Step 1. Wire to power supply

There are two ways to supply power to the XP-8000-CE6.

Single power supply



Tips & Warnings




Once you wire and power up the power supply, confirm the PWR indicator (Red LED) on the CPU module is on.

If the indicator is not on, check the voltage on the terminal block with a voltage meter. If you measure 24 VDC on the terminal block, the CPU module may be defective. Please contact us.

Redundant power supply


The redundant power can be used single and used two self-governed power to supply to the system, PWR1 and PWR2 input at the same time, when one power fails, the other power acts as a backup, and automatically supplies power needs.




Step 2. Check the boot status

When powering on the XP-8000-CE6, please note the four LED statuses to make sure the boot is correct. The booting process takes about 40~50 seconds.


i. Switch the power switch to the on position




After power on, the LED will be on.



ii. Load BIOS




iii. Enter the welcome screen



iv. Start to load OS



v. OS load successfully



vi. The boot process has been finished successfully.

Tips & Warnings




After the boot process has been finished, the L1 and L2 LED indicators will be released. The user can use XPAC API to control them.

The LED light status of XP-8x31-CE6 is different in phase 1 and the status is same in the other phase.

2.2. Configuring the Boot Mode

The XP-8000-CE6 has several operating modes, which can be selected by a rotary switch.



The table below lists the operation modes available with the XP-8000.

Position	Operating Mode
0	Normal mode (Default)
1	Safe mode
2	(For user defined mode)
3	(For user defined mode)
4	(For user defined mode)
5	(For user defined mode)
6	(For user defined mode)
7	(For user defined mode)
8	DCON_CE
9	Remote Display mode

The following is a brief introduction of these modes.

Normal Mode (Default mode)

Normal mode is the default mode of operation and the one you will use most of the time. Use this mode for more tasks and configurations. Programs also are executed in this mode.

Safe Mode

Safe mode is a troubleshooting mode. The mode loads the minimum required device drivers and system services to boot the XP-8000-CE6.

If you have malicious software or a program caused the XP-8000-CE6 cannot be boot or run the normal mode, you can boot in safe mode to solve the problem.

DCON_CE

In this mode, the DCON_CE will be run automatically, and other settings are same as the normal mode.

For more information about the DCON CE, please refer to section 3.3. DCON CE.

Remote Display

In this mode, the cerdisp.exe will be run automatically, and other settings are same as the normal mode.

For more information about the Remote Display, please refer to section 2.5. Using Remote Display to Control the XP-8000-CE6 Remotely.

User Mode


The positions 2~7 of rotary switch are reserved for user's applications.

When XP-8000-CE6 is boot with one of these positions, it is boot at normal mode. User's application can check the position of the rotary switch position to run at different mode.

2.3. Changing the User Interface Language

This section describes how to change the XP-8000-CE6 user interface to your native language using the Windows CE Regional and Language Settings.


Step 1: Click the **[Start]** menu, point to **[Settings]**, click **[Control Panel]**, and then click **[Regional Settings]**.



Step 2: Click the **[User Interface Language]** tab, select your local language, and then click **[OK]**.



Step 3: Double-click the **[XPAC Utility]** on the desktop and reboot the XP-8000-CE6 to apply the changes.




2.4. Using XPAC Utility to Manage the XP-8000

The XPAC Utility is a built-in management tool that provides functions including IP configuration, FTP server settings, and system information diagnostics.


For more detailed information on XPAC Utility applications, please refer to “3.1. XPAC Utility”

Step 1: Launch the [XPAC Utility] located on the desktop.

Step 2: Modify the settings under the relevant tabs as needed (e.g., IP address, Auto-execution programs).



Step 3: Click [File] > [Save and Reboot] to restart the system and save the configurations.



2.5. Using Remote Display to Control the XP-8000-CE6 Remotely

Remote Display tool allows users to operate the XP-8000-CE6 desktop environment from a PC for remote monitoring and control.

Step 1: Go to the Download Center, click **[WinCE6.0 PACs]** in the **[Utility & Tools]** section, and download the **Remote Display Application**.

Users can also access the download page for XP-8000-CE6 related utilities via the following official download link.

<https://www.icpdas.com/en/download/show.php?num=763>

The screenshot shows the ICPDAS download center interface. The top section is titled "Utility & Tools" and contains a table with the following data:

FILE NAME	DESCRIPTION	MODEL	LAST UPDATE
DCON Utility Pro WinCE6.0 version	For WinCE 6.0 PAC	XP-8000-CE6 Series	2022-09-21
CEP	Utility & Tools	XP-8000-CE6 Series	2025-10-21
WinCE6.0 PACs	Utility & Tools	XP-8000-CE6 Series	2024-11-20


A blue arrow points from the "WinCE6.0 PACs" link in the table to the "WinCE6.0 PACs" section below. This section is titled "WinCE6.0 PACs" and contains a table with the following data:

UTILITY/TOOLS	FILE NAME	VERSION	SIZE	DOWNLOAD
XPAC Utility	XPAC_Utility_WinCE6.0_x86.zip	1.0.3.1	394 KB	
DCON Utility Pro	-	-	-	
Windows CE Task Manager	TaskMgr_WinCE6.0_x86.zip	-	1 KB	
Remote Display Application	Remote_Display_WinCE6.0_x86.zip	-	1 KB	


Step 2: After unzipping the file on the PC, execute the **cerhost.exe** client program.



Step 3: On the XPAC side, execute the server program **cerdisp.exe** located at
\\System_Disk\\Tools\\Remote_Display
and click [OK].



Step 4: In **cerhost.exe** on the PC, click [File] > [Connect] and enter the IP address of the XPAC to establish the connection.




2.6. Using DCON Utility Pro Configure I/O Modules


DCON Utility Pro allows users to configure and manage the I/O modules via Ethernet or serial ports (RS-232/RS-485).

Step 1: Double-click [DCON_Utility_Pro] on the desktop to launch the application.


Step 2: Click the  icon button to enter the communication configuration interface.



Step 2: Select the communication interface (COM Port) and parameters, then click [Start Search].




Step 3: Select the correct communication interface (e.g., COM1 [Backplane]) and parameters, then click **[OK]**.



Tips & Warnings



The COM port settings for expansion I/O modules are listed below.




COM 2/3/4/5

For more information on these COM port selections, please refer to the specification of the pin assignments in section 1.3. Overview

Step 4: Click the [] button to scan for connected I/O modules.

Step 5: Click the identified module name from the list to enter the detailed I/O setting page for parameter adjustment.

Step 6: After completing the configuration, click **[Write Configurations to I/O Module]** to save the settings to the module.



2.7. Using DCON_CE to Remote Configure the I/O Module

The DCON Utility is a PC-based client utility that uses the DCON protocol to remotely connect and manage I-7K and I-87K series I/O modules on the XP-8000-CE6.

Step 1: Go to the Download Center, click **[WinCE6.0 PACs]** in the **[Utility & Tools]** section, and download the **DCON Utility Pro WinCE6.0 version**.

Users can also access the download page for XP-8000-CE6 related utilities via the following official download link.

<https://www.icpdas.com/en/download/show.php?num=1044>

Utility & Tools


FILE NAME	DESCRIPTION	MODEL	LAST UPDATE
DCON Utility Pro WinCE6.0 version	For WinCE 6.0 PAC	XP-8000-CE6 Series	2022-09-21
VCEP	Utility & Tools	XP-8000	2025-10-21

DCON Utility Pro WinCE6.0 version

FILE NAME	VERSION	FILE DATE	SIZE	NOTE	
DCON_Utility_Pro_CE6_V4003		2021-03-17	17 MB		


Step 2: After unzipping the file on the PC, install the **DCON Utility Pro**.

Step 3: On the XPAC side, run the server program **DCON_CE_XP** located under
\\System_Disk\\Tools\\DCON_CE




Step 4: On the PC side, launch **DCON Utility**.

Step 5: Click the **[WINCE]** common button and switch to the **[XPAC_CE]** tab.



Step 4: Type the IP address of the XPAC and click **[Connect to XPAC_CE]** to establish the connection.




Tips & Warnings



If DCON Utility cannot connect to XP-8000-CE6, the Ethernet connection between Host PC and XP-8000-CE6 might be rejected by fire wall, please contact with MIS to open the Ethernet port.

Step 5: Once connected, click the module name from the list to perform remote configuration.



Tips & Warnings



If there is no operation within 30 seconds, the connection will automatically close to release the COM port occupied.



3. Tools and Tasks

This chapter provides a brief introduction to the XP-8000-CE6 service tools and their benefits.

There are several tools and utilities built-in and designed for use with the XP-8000-CE6. Some of these are pre-installed on the XP-8000-CE6 and can be operated directly on the device, while others are supporting tools designed to help you manage the XP-8000-CE6 remotely from a PC.

Access the official download page

Users can directly use the pre-installed tools or obtain the latest versions of supporting software through the ICP DAS Official Download Center.

<https://www.icpdas.com/en/download/show.php?num=763>

**WinCE6.0 PACs**

UTILITY/TOOLS	FILE NAME	VERSION	SIZE	DOWNLOAD
XPAC Utility	XPAC_Utility_WinCE6.0_x86.zip	1.0.3.1	394 KB	
DCON Utility Pro	-	-	-	
Windows CE Task Manager	TaskMgr_WinCE6.0_x86.zip	-	1 KB	
Virtual CE Pro	-	-	-	
Remote Display Application	Remote_Display_WinCE6.0_x86.zip	-	1 KB	
Registry Editor	RegEdit_WinCE6.0_x86.zip	1.2.0.0	1 KB	

3.1. XPAC Utility

XPAC Utility is a collection of software applications that enable management and configuration of XP-8000-CE6 system and features.




The XPAC Utility includes the following menu bars and property tabs. All of these functions will be explained later.


Menu bar	Property Tab
File	General
Help	General2
	Display
	IP Config
	Network
	Device Information
	Auto Execution
	Rotary Execution
	Multi-IO Module
	Backplane Compatibility

3.1.1. Menu Bar – File

By default, the available default items are shown to the right.




All menu items will be enabled when the **Manual Save To Flash** option is selected.



The menus use to	How to use
Save	By default, this item is disabled until the Manual Save To Flash option is selected. Saves the changes.
Save and Reboot	By default, this item is disabled until the Manual Save To Flash option is selected. Saves the changes and reboots the XP-8000-CE6.
Reboot	Restarts the XP-8000-CE6.
Restore Utility Default Settings	Restore the XP-8000-CE6 to default settings.
Exit	Exits the XPAC Utility.


3.1.2. Menu Bar – Help




The menus use to	How to use
About	Displays a dialog box with information about XPAC Utility, including the current version and copyright information.

3.1.3. Property Tab - General

The **General** tab provides functions to configure the task bar, check the status of the battery..., etc.



The tab use to	How to use
Lock or Auto-Hide the taskbar	Auto-Hide the taskbar: Select the Auto Hide check box. Lock the taskbar: Select the Always On Top check box.
Auto save or manual save to flash	Auto save to flash: Select the Auto Save To Flash (Default) check box. Any changes made to the XP-8000-CE6 will be saved and only take effect after the XP-8000-CE6 reboots. Manual save to flash: Select the Manual Save to Flash check box. Any changes made to the XP-8000-CE6 will be saved by clicking the Save and Reboot from File menu.



The tab use to	How to use
Enable USB autorun	Select the Enable Autorun in plugging USB Disk check box.
Monitor the information of battery 1 and battery 2	See the Battery1 and Battery2 field that displays the battery status.
Automatic synchronization of system time	Refer to the Appendix A.2. How to configure the service for automatically synchronizing with the internet time server.

3.1.4. Property Tab – General2


The **General2** tab provides functions to specify the name of the USB disk.



The tab use to	How to use
Specify the name of the USB disk	Enter a name in the USB Hard Disk: field, and then click the Set button.

3.1.5. Property Tab – Display

The **Display** tab provides functions to configure the monitor settings.



The tab use to	How to use
Adjust the screen resolution	Move the slider to the left to decrease the resolution or move the slider to the right to increase the resolution, and then click the Apply button.
Change the screen refresh rate	Select the desired refresh rate from the Screen refresh rate drop-down list, and then click the Apply button.
Display depth	Select the “16 bit” or “32 bit” to setting the display depth, and then click the Apply button. The display depth default setting is “16 bit”.

3.1.6. Property Tab – IP Config

The **IP Config** tab provides functions to configure either DHCP (Roaming) or manually configured (Static) network settings and to monitor the MAC address. Generally, DHCP is the default settings, but if you don't have a DHCP server, you must configure the network settings by using manual configuration.

XPAC Utility [1.2.2.0]

File Help

General General2 Display **IP Config** Network Device Information Auto Execution Rotary Exe

LAN 1:

MAC Address: 00-0D-E0-30-25-32

☒ Use DHCP to get IP address

☐ Assign IP address

IP Address: 10.1.0.49

Mask: 255.255.0.0

Gateway: 10.1.0.254

DNS Server: 10.0.0.3

Apply

LAN 2:

MAC Address: 00-0D-E0-30-25-32

☒ Use DHCP to get IP address

☐ Assign IP address

IP Address:

Mask:

Gateway:

DNS Server:

Apply


The tab use to	How to use
Set the network settings	Use DHCP to get IP address: Select the Use DHCP to get IP address option, and then click the Apply button. Assign an IP address: Select the Assign IP address option, and then click the Apply button.

3.1.7. Property Tab – Network

The **Network** tab comprises three tabs – Access, Login and File Server Settings.

Access

The **Access** tab provides functions to enable/disable the FTP access, enable/disable anonymous FTP access, and configure the FTP and HTTP directory path.




The tab use to	How to use
Enable or disable the FTP access	Enable the FTP access: Select the Enable check box in the FTP field, and then click the Apply button. Disable the FTP access: Select the Disable check box in the FTP field, and then click the Apply button.

The tab use to	How to use
Enable or disable anonymous FTP access	Enable anonymous FTP access: Select the Enable check box in the Allow Anonymous field, and then click the Apply button. Disable anonymous FTP access: Select the Disable check box in the Allow Anonymous field, and then click the Apply button.
Set the FTP directory path	Enter a new path in the Set FTP default download directory to: field, and then click the Apply button.
Set the HTTP directory path	Enter a new path in the Set HTTP document root directory to: field, and then click the Apply button.

Login


The **Login** tab provides functions to maintain the FTP accounts.



The tab use to	How to use
Maintain the FTP accounts	Refer to the Appendix D.1 How to add a user account to remote login the XP-8000-CE6 from PC.

File Server Settings

The **File Server Settings** tab provides functions to set the SMB server.



The tab use to


How to use

Set the SMB server

Click the Settings button to set the SMB server path.

3.1.8. Property Tab – Device Information

The **Device Information** tab provides functions to monitor necessary system information of the XP-8000. The information is the most important note of version control for upgrading system.



Slot	Parameter	Value
Slot 1:	CPU Type:	R3600
Slot 2:	Serial Number:	01-BD-FA-C6-19-00-00-9F
Slot 3:	Backplane Version:	1.0.13.0
Slot 4:	CPU Version:	1.0.0.0
Slot 5:	OS Version:	1.2.0.0
Slot 6:	.NET CF Version:	3.5.7338.00
Slot 7:	SQL CE Version:	3.5.8080.0
	XPacSDK Version:	4.4.1.0


3.1.9. Property Tab – Auto Execution

The **Auto Execution** tab provides functions to configure programs running at XP-8000-CE6 startup, it allows users to configure ten execute files at most.

Tips & Warnings




The specific extensions are .exe and .bat, and they are executed in order of program 1, program 2, etc.



The tab use to	How to use
Configure programs running at startup	Click the Browse button to select the execute file which you want, and then click the Apply button.

3.1.10. Property Tab – Rotary Execution

The Rotary Execution tab provides function to decide which mode XP-8000-CE6 executes at startup.




The tab use to	How to use
Start XP-8000-CE6 in normal mode	Turn the rotary switch in position 0 and reboot the XP-8000-CE6. By default, this item is disabled.
Start XP-8000-CE6 in safe mode	Turn the rotary switch in position 1 and reboot the XP-8000-CE6. By default, this item is disabled.
Start XP-8000-CE6 in normal mode and auto execute the user-specified program	Click the Browse button to select the execute file which you want, click the Apply button, and then turn the rotary switch in position 2/3/4/5/6/7 and reboot the XP-8000-CE6.
Start XP-8000-CE6 in normal mode and auto execute the DCON CE utility	Turn the rotary switch in position 8 and reboot the XP-8000-CE6. By default, this item is disabled.
Start XP-8000-CE6 in normal mode and auto execute the Remote Display server	Turn the rotary switch in position 9 and reboot the XP-8000-CE6. By default, this item is disabled.

3.1.11. Property Tab – Multi-IO Modules

The Multi-serial port provides functions for installation of the RS-232/RS-422/RS-485 communication module driver.

The table below shows the expansion RS-232/RS-422/RS-485 communication modules that are compatible with the XP-8000-CE6.

Item	RS-232	RS-422/RS-485	Isolation	Connector
I-8112iW	2	-	2500 Vrms	DB-9 x 2
I-8114W	4	-	-	DB-37 x 1
I-8114iW	4	-	2500 Vrms	DB-37 x 1
I-8142iW	-	2	2500 Vrms	Terminator block x 1
I-8144iW	-	4	2500 Vrms	Terminator block x 1



The tab use to	How to use
Set the port name	Select the name type and order type from the Selection COM Port Type and Select order type options, and then click the Set button.


3.2. DCON Utility Pro

DCON Utility Pro enables users easily to configure and manage the I/O modules via Ethernet or serial ports (RS-232/RS-485).

For more information on how to use DCON Utility Pro to configure I/O modules, please refer to 2.6. Using DCON Utility Pro to Configure I/O Modules

For more detailed information on DCON Utility application, please refer to:

https://www.icpdas.com/en/product/guide+Software+Utility_Driver+DCON_Utility_Pro



3.3. DCON_CE


The DCON_CE is a server program based that runs on XP-8000-CE6, and communicates with PC via DCON protocol.

The DCON Utility is a client utility that runs on PC, and communicates with XP-8000-CE6 via DCON protocol. The DCON Utility allows users to remotely connect to I-7K and I-87K series I/O modules for management through the COM port and Ethernet port.

This tool is composed of two parts, a client and a server. The server is a program named DCON_CE_XP running on XP-8000-CE6. The client is a PC-based program named DCON Utility running on the PC.


3.4. TaskMgr

The TaskMgr is a Windows CE application, which provides real time info on all processes and threads including System threads, similar in appearance to the Windows Task Manager.



3.5. VCEP

ICP DAS VCEP is designed for managing your XP-8000-CE6 anywhere. No matter where you are, ICP DAS VCEP provides a convenient environment on the Desktop PC and lets you control your XP-8000-CE6 remotely.



ICP DAS VCEP is composed of two main components: The **Server** which runs on XP-8000-CE6 and the **Client** which runs on a Desktop PC.

Once a connection is established between the client and server (initiated by the client), the client will periodically send requests for screen updates and send mouse/key click information to the server to simulate.

Each video frame is inter-compressed against the previous frame and then intra-compressed with a modified LZW scheme to minimize the amount of data transmitted from server to client.

For more detailed information on VCEP application, please refer to

[https://www.icpdas.com/en/product/guide+Software+Applications+VCEP_\(Virtual_CE_Pro\)](https://www.icpdas.com/en/product/guide+Software+Applications+VCEP_(Virtual_CE_Pro))

3.6. Remote_Display

The **Remote Display** allows XP-8000-CE6 to be controlled and monitored from a remote location.

This tool is composed of two parts, a client and a server. The server is a program named cerdisp.exe running on XP-8000-CE6. The client is a PC-based program named cerhost.exe running on the PC.

Once a connection is established between the client and server (initiated by the client), the client will periodically send requests for screen updates and send mouse/key click information to the server to simulate.

3.7. SendToCOM

The **SendToCOM** uses the serial port to communicate with expansion module. To use the SendToCOM, you can send data to expansion module through the serial port, and receive data from other device through the serial port.

For more information about these commands for communicating with expansion module, please refer to:

[https://www.icpdas.com/en/product/guide+Remote I O Module and Unit+PAC I O Modules+I-8K I-87K Series \(High Profile\)](https://www.icpdas.com/en/product/guide+Remote+I+O+Module+and+Unit+PAC+I+O+Modules+I-8K+I-87K+Series+(High+Profile))

ICPDAS Send to COM V1.0.4 2011/2/23

Connection Status

COM Port: COM2 Baudrate: 115200 Data Bit: 8 Parity: 0-None Parity Stop Bit: 1 Slot: []

Open Close

End string with: ☒ None ☐ LF_CR ☐ CR ☐ CR_LF ☐ LF

string ☒ +CRC ☐ Binary ☒ String Send Polling

Auto send Interval (ms): 500 Start Stop Set

Start Time: [] Stop Time: []

Commands Responses


Current Packet Size (bytes)	0	Current Packet Size (bytes)	0
Total Packet Bytes	0	Total Packet Bytes	0
Packet Quantity send	0	Packet Quantity received	0

Clear

Clear


3.8. RegEdit

The **RegEdit** provides a hierarchical representation of the registry on a target computer, similar in appearance to the Windows Registry Editor. The standard registry roots are represented; you can add keys beneath a root to point to existing registry keys, or you can add your own keys. Values can be changed for existing keys, or added for new keys, and default keys can be specified.




3.9. ISQLW35

The **ISQLW35** is a Windows Embedded Compact 6 functionality that implements SQL Server Compact 3.5 Query.



3.10. INotepad

The **INotepad** is a common text-only editor. The resulting files have no format tags or styles.



4. Your First XP-8000-CE6 Program

This chapter provides a guided tour that describes the steps needed to set-up a development environment, download, install, and configure for user programming with XP-8000-CE6.

4.1. Setting up the Development Environment

Before writing your first program, ensure that you have the necessary development tools and the corresponding SDKs installed on your system.

4.1.1. Preparing the Development Tools

XP-8000-CE6 has .NET Compact Framework 3.5 installed. Visual Studio takes full advantage of the .NET Compact Framework, which uses public Internet standards to enable integration with applications running on any platform.

Supported languages include

- Visual Basic.NET
- Visual C#
- Visual C++

Tips & Warnings



1. There is no support for development of both managed and unmanaged code on XP-8000-CE6 platform in VS2010/VS2012.
2. WinCE-based platform development is only supported in Visual studio Professional edition or better, no Express or Standard edition.

The table below provides a summary of the supported development tools and languages required for developing XP-8000-CE6 applications.

Development Tool \ Language		Visual Basic .Net	Visual C#	Visual C++
Visual Studio 2005 or earlier	Any version except Professional	--	--	--
	Professional	✓	✓	✓
Visual Studio 2008	Any version except Professional	--	--	--
	Professional	✓	✓	✓
Visual Studio 2010 or later	Any version except Professional	--	--	--
	Professional	--	--	--

✓: Supported, --: Unsupported

4.1.2. Installing the XP-8000-CE6 SDK

The XP-8000-CE6 SDK offers several APIs for customizing the standard features and integrating with other applications, devices and services.

Step 1: Go to the Download Center, click **[WinCE6.0 PACs]** in the **[SDK]** section, and download the **PlatformSDK**.

Direct Link:

<https://www.icpdas.com/en/download/show.php?num=2473>

SDK

FILE NAME	DESCRIPTION	MODEL	LAST UPDATE
WinCE6.0 PACs	SDK and Demo Samples	XP-8000-CE6 Series	2025-12-03

SDK Selection

☐ PACSDK

PACSDK

SDK	FILE NAME	DESCRIPTION	VERSION	SIZE	DOWNLOAD
PlatformSDK	PlatformSDK.zip	PAC SDK for Windows PC	1.5.0	9.34 MB	
PACNET	PACNET_CE6_x86.zip	and C#	2.1.0.8	211 KB	
		PAC LIBRARY for Visual			

Step 2: After unzipping the file on the PC, install **PACSDK_CE_n.n.n_Vxxxx.msi** and follow the prompts to complete the process

4.2. First XP-8000-CE6 Program in VB.NET

The best way to learn programming with XP-8000-CE6 is to actually create a XP-8000-CE6 program.

The example below demonstrates how to create a demo program running on XP-8000-CE6 with VB.NET.

To create a demo program with VB.NET that includes the following main steps:

1. Create a new project
2. Specify the path of the PAC reference
3. Add the control to the form
4. Add the event handling for the control
5. Upload the application to XP-8000-CE6
6. Execute the application on XP-8000-CE6

All main steps will be described in the following subsection.

In this tutorial, we will assume that you have installed XP-8000-CE6 SDK on PC and used the Visual Studio 2008 for application development.


4.2.1. Create a new project

The Visual VB.net project template is a composite control that you use in this example creates a new project with this user control.

Step 1: Start Visual Studio 2008




Step 2: On the File menu, point to New, and then click Project



Step 3: In the Project types pane, expand Visual Basic node and select Smart Device

Step 4: In the list of Templates, select Smart Device Project


Step 5: Specify a name and a location for the application and then click OK



Step 6: In the Target platform, select Windows CE

Step 7: In the .NET Compact Framework version, select .NET Compact Framework Version 3.5.

Step 8: In the list of templates, select Device Application. Click OK



4.2.2. Specify the path of the PAC reference

The PAC SDK provides a complete solution to integrate with XP-8000-CE6 and it's compatible with Visual C#, Visual Basic.NET and C++. In order to use a component in your application, you must first add a reference to it.


Step1: Get the PACNET.dll




The PACNET.dll can be found by downloading the latest version from ICP DAS web site.

<http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/sdk/xpacnet/pacnet/>

Step 2: On the Project menu, and then click Add Reference...



Step 3: On the Browse tab and browse to where the PACNET.dll are installed, and then click OK




4.2.3. Add the control to the form


You can drag various controls from the Toolbox onto the form. These controls are not really "live"; they are just images that are convenient to move around on the form into a precise location.

After you add a control to your form, you can use the Properties window to set its properties, such as background color and default text. The values that you specify in the Properties window are the initial values that will be assigned to that property when the control is created at run time.

Step 1: On the Toolbox panel, drag a Button control onto the form




Step 2: On the Properties panel, type Check the SDK version in the Text field



4.2.4. Add the event handling for the control

You have finished the design stage of your application and are at the point when you can start adding some code to provide the program's functionality.

Step 1: Double-click the button on the form



Step 2: Inserting the following code

```
Dim data(30) As Byte  
PACNET.Sys.GetSDKVersion(data)  
MessageBox.Show(PACNET.MISC.WideString(data))
```

```
Public Class Form1  
    Private Sub Button1_Click(ByVal sender As System.Object, ByVal e As  
        Dim data(30) As Byte  
        PACNET.Sys.GetSDKVersion(data)  
        MessageBox.Show(PACNET.MISC.WideString(data))  
    End Sub  
End Class
```


Tips & Warnings




The "PACNET" of "using PACNET" is case- sensitive.

4.2.5. Upload the application to XP-8000-CE6

XP-8000-CE6 supports FTP server service. You can upload files to XP-8000-CE6 or download files from a public FTP server.



Step 1: On the Build menu, and then click Build [Project Name]




Step 2: Open the browser and type the IP address of XP-8000-CE6

Step 3: Upload the application and the corresponding PACNET.dll files to XP-8000-CE6

Tips & Warnings




For applications programming in C# and VB.net with .net compact framework, when executing these application on XP-8000-CE6, the corresponding PACNET.dll must be in the same directory as the .exe file.



4.2.6. Execute the application on XP-8000-CE6

After uploading the application to XP-8000-CE6, you can just double-click it on XP-8000-CE6 to execute it.



4.3. First XP-8000-CE6 Program in Visual C#

The best way to learn programming with XP-8000-CE6 is to actually create a XP-8000-CE6 program.

The example below demonstrates how to create a demo program running on XP-8000-CE6 with Visual C#.

To create a demo program with Visual C# that includes the following main steps:

1. Create a new project
2. Specify the path of the PAC reference
3. Add the control to the form
4. Add the event handling for the control
5. Upload the application to XP-8000-CE6
6. Execute the application on XP-8000-CE6

All main steps will be described in the following subsection.

In this tutorial, we will assume that you have installed XP-8000-CE6 SDK on PC and used the Visual Studio 2008 for application development.


4.3.1. Create a new project

The Visual C# project template is a composite control that you use in this example creates a new project with this user control.

Step 1: Start Visual Studio 2008




Step 2: On the File menu, point to New, and then click Project



Step 3: In the Project types pane, expand Visual C# node and select Smart Device

Step 4: In the list of Templates, select Smart Device Project


Step 5: Specify a name and a location for the application and then click OK



Step 6: In the Target platform, select Windows CE

Step 7: In the .NET Compact Framework version, select .NET Compact Framework Version 3.5.

Step 8: In the list of templates, select Device Application. Click OK



4.3.2. Specify the path of the PAC reference

The PAC SDK provides a complete solution to integrate with XP-8000-CE6 and it's compatible with Visual C#, Visual Basic.NET and C++. In order to use a component in your application, you must first add a reference to it.


Step1: Get the PACNET.dll




The PACNET.dll can be found by downloading the latest version from ICP DAS web site.

<http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/sdk/xpacnet/pacnet/>

Step 2: On the Project menu, and then click Add Reference...



Step 3: On the Browse tab and browse to where the PACNET.dll are installed, and then click OK




4.3.3. Add the control to the form


You can drag various controls from the Toolbox onto the form. These controls are not really "live"; they are just images that are convenient to move around on the form into a precise location.

After you add a control to your form, you can use the Properties window to set its properties, such as background color and default text. The values that you specify in the Properties window are the initial values that will be assigned to that property when the control is created at run time.

Step 1: On the Toolbox panel, drag a Button control onto the form




Step 2: On the Properties panel, type Check the SDK version in the Text field



4.3.4. Add the event handling for the control


You have finished the design stage of your application and are at the point when you can start adding some code to provide the program's functionality.

Step 1: Double-click the button on the form



Step 2: Inserting the following code

```
byte[] data = new byte[30];  
PACNET.Sys.GetSDKVersion(data);  
MessageBox.Show(PACNET.MISC.WideString(data));
```




Tips & Warnings




The "PACNET" of "using PACNET" is case- sensitive.

4.3.5. Upload the application to XP-8000-CE6

XP-8000-CE6 supports FTP server service. You can upload files to XP-8000-CE6 or download files from a public FTP server.



Step 1: On the Build menu, and then click Build [Project Name]




Step 2: Open the browser and type the IP address of XP-8000-CE6

Step 3: Upload the application and the corresponding PACNET.dll files to XP-8000-CE6

Tips & Warnings




For applications programming in C# and VB.net with .net compact framework, when executing these application on XP-8000-CE6, the corresponding PACNET.dll must be in the same directory as the .exe file.



4.3.6. Execute the application on XP-8000-CE6

After uploading the application to XP-8000-CE6, you can just double-click it on XP-8000-CE6 to execute it.



4.4. First XP-8000-CE6 Program in Visual C++

The best way to learn programming with XP-8000-CE6 is to actually create a XP-8000-CE6 program.

The example below demonstrates how to create a demo program running on XP-8000-CE6 with Visual C++.

To create a demo program with Visual C# that includes the following main steps:

1. Create a new project
2. Configure the Platform
3. Include the Header files and Libraries of the PAC SDK
4. Add the control to the form
5. Add the event handling for the control
6. Upload the application to XP-8000-CE6
7. Execute the application on XP-8000-CE6

All main steps will be described in the following subsection.

In this tutorial, we will assume that you have installed XP-8000-CE6 SDK on PC and used the Visual Studio 2008 for application development.


4.4.1. Create a new project

The Visual C# project template is a composite control that you use in this example creates a new project with this user control.

Step 1: Start Visual Studio 2008




Step 2: On the File menu, point to New, and then click Project




Step 3: In the Project types pane, expand Visual C++ node and select Smart Device

Step 4: In the list of Templates, select MFC Smart Device Application


Step 5: Specify a name and a location for the application and then click OK




Step 6: On the first page of the wizard, click Next




Step 7: On the next page of the wizard, select XPacSDK CE to be added to the project, and then click Next




Step 8: On the next page of the wizard, select Dialog based, and then click next




Step 9: On the next page of the wizard, click next



Step 10: On the next page of the wizard, click next




Step 11: On the next page of the wizard, click Finish



4.4.2. Configure the Platform

When developing applications by using Visual C++, you must configure the Platform to indicate what platform and device you intend to download the application to. Before you deploy your project, check the platform.

On the Debug configuration toolbar, select Release and select XPacSDK_CE(x86) as shown in the following illustration.




4.4.3. Specify the Libraries of the PAC SDK

The PAC SDK provides the PACSDK libraries with XP-8000-CE6.


It's compatible with C++. In order to use a component in your application, you must first add a reference to it.

Step 1: On the View menu, and then click Property Pages



Step 2: In left pane, click Linker, and then click Input

Step 3: In the right pane, Type PACSDK.lib in the Additional Dependencies item




4.4.4. Add the control to the form


You can drag various controls from the Toolbox onto the form. These controls are not really "live"; they are just images that are convenient to move around on the form into a precise location.

After you add a control to your form, you can use the Properties window to set its properties, such as background color and default text. The values that you specify in the Properties window are the initial values that will be assigned to that property when the control is created at run time.


Step 1: On the View menu, and then click Resource View




Step 2: In the Resource View Panel, Expand the [Project name].rc file and then expand the Dialog item to click the plug-in dialog



Step 3: On the Toolbox panel, drag a Button control onto the form




Step 4: On the Properties panel, type Check the SDK version in the Caption field



4.4.5. Add the event handling for the control

You have finished the design stage of your application and are at the point when you can start adding some code to provide the program's functionality.

Step 1: Double-click the button on the form




Step 2: Inserting the following code

```
char sdk_version[32];  
TCHAR buf[32];  
pac_GetSDKVersion(sdk_version);  
pac_AnsiToWideString(sdk_version, buf);  
MessageBox(buf,0,MB_OK);
```

```
void CSDK_InfoDlg::OnBnClickedButton1()  
{  
    // TODO: Add your control notification handler code here  
    char sdk_version[32];  
    TCHAR buf[32];  
    pac_GetSDKVersion(sdk_version);  
    pac_AnsiToWideString(sdk_version, buf);  
    MessageBox(buf,0,MB_OK);  
}
```

Step 2: Inserting the following code into the header area

#include "PACSDK.h"




```
// SDK_InfoDlg.cpp : implementation file
//

#include "stdafx.h"
#include "SDK_Info.h"
#include "SDK_InfoDlg.h"
#include "PACSDK.h"


#ifdef _DEBUG
```

4.4.6. Upload the application to XP-8000-CE6

XP-8000-CE6 supports FTP server service. You can upload files to XP-8000-CE6 or download files from a public FTP server.




Step 1: On the Build menu, and then click Build [Project Name]




Step 2: Open the browser and type the IP address of XP-8000-CE6

Step 3: Upload the application to XP-8000-CE6



4.4.7. Execute the application on XP-8000-CE6


After uploading the application to XP-8000-CE6, you can just double-click it on XP-8000-CE6 to execute it.



5. I/O Expansion Modules and SDKs Selection

This chapter describes how to select a suitable expansion I/O module and the corresponding SDK library to be used for developing programs on XP-8000-CE6.

XP-8000-CE6 provides the following I/O expansion buses:



1. RS-485

I-7000, M-7000, RU-87Pn and high profile I-87K series modules connect to XP-8000-CE6 via a twisted-pair, multi-drop, 2-wire RS-485 network.

➤ I-7000 series I/O module

Module	Native SDK	.NET CF SDK
I-7000 series	PACSDK.dll	PACNET.dll
I-7000 series with I-7088 (D)	PACSDK_PWM.dll	PACNET.dll

For full details regarding I-7000 series I/O modules and its demos, please refer to:

http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/demo/ypac/applicable_demo_for_7k_module.pdf

➤ M-7000 series I/O module

Module	Native SDK	.NET CF SDK
M-7000 series	Modbus Demo	Modbus Demo

For more detailed information about M-7000 series modules using Modbus protocol and its demos, please refer to:

<https://www.icpdas.com/en/download/show.php?num=2473>

➤ RU-87Pn + I-87K series I/O module

Module	Native SDK	.NET CF SDK
RU-87Pn+I-87K series	PACSDK.dll	PACNET.dll

➤ Other Specified I/O

Module	Native SDK	.NET CF SDK
Others	PACSDK.dll	PACNET.dll

2. Ethernet

The Ethernet I/O devices available include ET-7000 and I-8KE4/8-MTCP, and support either the DCON or the Modbus/TCP communication protocol.

Module	Native SDK	.NET CF SDK
M-7000 series	Modbus Demo	Modbus Demo
I-8KE4/8-MTCP	Modbus Demo	Modbus Demo

For more detailed information about ET-7000 and I-8KE4/8-MTCP series modules using Modbus protocol and its demos, please refer to:

<https://www.icpdas.com/en/download/show.php?num=2473>

3. Local I/O

XP-8000-CE6 has 0/1/3/7 expansion slot(s) that can be used to add expansion I/O modules. The expansion I/O modules can be divided into two categories: High Profile I-8K series I/O modules and High profile I-87K series I/O modules. The following indicates the appropriate SDK library to be used for I/O modules.

➤ General I-8K/I-87K series I/O module

Module	Native SDK	.NET CF SDK
I-8K series	PACSDK.dll	PACNET.dll
I-87K series	PACSDK.dll	PACNET.dll

For full details regarding I-87K series I/O modules and its demos, please refer to:

http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/demo/ypac/applicable_demo_for_87k_module.pdf

➤ Other Specified I/O

Module	Native SDK	.NET CF SDK
I-8014W	pac_i8014W.dll	pac_i8014WNET.dll
I-8017HW	pac_i8017HW.dll	pac_i8017HWNET.dll
I-8024W	pac_i8024W.dll	pac_i8024WNET.dll
I-8026W	pac_i8026W.dll	pac_i8026WNET.dll
I-8048W	pac_i8048W.dll	pac_i8048WNET.dll
I-8050W	pac_i8050W.dll	pac_i8050WNET.dll
I-8084W	pac_i8084W.dll	pac_i8084WNET.dll
I-8088W	pac_i8088W.dll	pac_i8088WNET.dll
I-8093W	pac_i8093W.dll	pac_i8093WNET.dll
I-87088W	PACSDK_PWM.dll	PACNET.dll

4. FRnet

FRnet is an innovative industrial field bus technology that uses twisted pair cable as the transmission medium. The status of all I/O devices is updated on a fixed cycle, no matter how many FRnet I/O modules are connected to the FRnet network.

Module	Native SDK	.NET CF SDK
I-8172W	pac_i8172W.lib	pac8172WNet.dll

5. CAN Bus

The Controller Area Network (CAN) is a serial communication way, which efficiently supports distributed real-time control with a very high level of security. It provides the error-processing mechanisms and concepts of message priority. These features can improve the network reliability and transmission efficiency.


Module	Native SDK	.NET CF SDK
I-8120W	i8120.lib	i8120net_pac.dll

6. APIs and Demo References

This chapter provides a brief overview of PAC standard APIs and demos that have been designed for XP-8000-CE6 from the PAC SDK package.


ICP DAS provides a set of demos in different programming languages. You can examine the demo codes, which includes numerous comments, to familiarize yourself with the PAC APIs. This will allow developing your own applications quickly by modifying these demo programs.

For full usage information regarding the description, prototype and the arguments of the functions, please refer to the “PAC Standard API Manual”



6.1. PAC Standard APIs for System Operation

The diagram below shows the set of each system operation API provided in the PACSDK.



6.1.1. VB.NET Demos for PAC Standard APIs

The PAC SDK includes the following demos that demonstrate the use of the PAC Standard APIs in a VB.NET language environment.

The following demos can be found by downloading the latest version from ICP DAS web site.

<http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/demo/xbac/vb.net/standard/>

Folder	Demo	Explanation
BPtimer	BPtimer	Retrieves information about the hardware timer.
DeviceInformation	DeviceInformation	Retrieves information about the OS version, CPU version, SDK version, etc.
Diagnostic	Diagnostic	Retrieves information about the slot count and the module inserted in the backplane.
DIP	DIP	Retrieves information about the status of the DIP switch.
GetRotaryID	GetRotaryID	Retrieves information about the status of the rotary switch.
Memory	Memory	Shows how to read/write data values from/to the EEPROM or the backplane of the SRAM
RealTimeTest	RealTimeTest	Writes the managed code for the rich graphical user interface that does not require true real-time performance
Registry	Registry	Shows how to read/write data values from/to the registry.
UART	UART	Shows how to read the name of the local I/O module via a UART.
WatchDog	WatchDog	Displays information about how to operate the watchdog.

6.1.2. C# Demos for PAC Standard APIs

The PAC SDK includes the following demos that demonstrate the use of the PAC Standard APIs in a C# language environment.

The following demos can be found by downloading the latest version from ICP DAS web site.

<http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/demo/ypac/c%23/standard/>

Folder	Demo	Explanation
BPtimer	BPtimer	Retrieves information about the hardware timer.
DeviceInformation	DeviceInformation	Retrieves information about the OS version, CPU version, SDK version, etc.
Diagnostic	Diagnostic	Retrieves information about the slot count and the module inserted in the backplane.
DIP	DIP	Retrieves information about the status of the DIP switch.
GetRotaryID	GetRotaryID	Retrieves information about the status of the rotary switch.
Memory	Memory	Shows how to read/write data values from/to the EEPROM or the backplane of the SRAM
RealTimeTest	RealTimeTest	Writes the managed cod for the rich graphical user interface that does not require true real-time performance
Registry	Registry	Shows how to read/write data values from/to the registry.
UART	UART	Shows how to read the name of the local I/O module via a UART.
WatchDog	WatchDog	Displays information about how to operate the watchdog.

6.1.3. Visual C++ Demos for PAC Standard APIs

The PAC SDK includes the following demos that demonstrate the use of the PAC Standard APIs in a Visual C++ language environment.


The following demos can be found by downloading the latest version from ICP DAS web site.

<http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/demo/ypac/vc2005/standard/>

Folder	Demo	Explanation
BPtimer	BPtimer	Retrieves information about the hardware timer.
DeviceInformation	DeviceInformation	Retrieves information about the OS version, CPU version, SDK version, etc.
Diagnostic	Diagnostic	Retrieves information about the slot count and the module inserted in the backplane.
DIP	DIP	Retrieves information about the status of the DIP switch.
GetRotaryID	GetRotaryID	Retrieves information about the status of the rotary switch.
Memory	Memory	Shows how to read/write data values from/to the EEPROM or the backplane of the SRAM
RealTimeTest	RealTimeTest	Writes the managed cod for the rich graphical user interface that does not require true real-time performance
Registry	Registry	Shows how to read/write data values from/to the registry.
UART	UART	Shows how to read the name of the local I/O module via a UART.
WatchDog	WatchDog	Displays information about how to operate the watchdog.

6.2. PAC Standard APIs for PAC Expansion I/O

The diagram below shows the types of the PAC IO APIs provided in the PACSDK.



6.2.1. VB.net Demos for PAC Expansion I/O

The PAC SDK includes the following demos that demonstrate the use of the PAC expansion I/O in a VB.NET language environment.

The following demos can be found by downloading the latest version from ICP DAS web site.

<http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/demo/xbac/vb.net/io/>

Folder	Demo	Explanation
Local	find_io	Shows how to retrieve the module name and type which plugged in the XP-8000-CE6.
	8k_di	Shows how to read the DI values of DI module. This demo program is used by 8K series DI modules.
	8k_do	Shows how to write the DO values to DO module. This demo program is used by 8K series DO modules.
	8k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 8K series DIO modules.
	87k_basic	Shows how to send/receive a command/response application. This demo program is used by 87K series modules.
	87K_demo	Shows how use uart API and the IO modules located as slots. This demo program is used by 87K series modules.
	87k_ai	Shows how to read the AI values of AI module. This demo program is used by 87K series AI modules.
	87k_ao	Shows how to write the AO values to AO module. This demo program is used by 87K series AO modules.
	87k_di	Shows how to read the DI values of DI module. This demo program is used by 87K series DI modules.
Local	87k_do	Shows how to write the DO values to DO module. This demo program is used by 87K series DO modules.
	87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 87K series DIO modules.
Remote	7k87k_basic	Shows how to send/receive a command/response application. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_ai	Shows how to read the AI values of AI module. This demo program is used by 7K or 87K series

Folder	Demo	Explanation
		AI modules which connected through a COM port.
	7k87k_ao	Shows how to write the AO values to AO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_di	Shows how to read the DI values of DI module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_do	Shows how to write the DO values to DO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.

6.2.2. C# Demos for PAC Expansion I/O

The PAC SDK includes the following demos that demonstrate the use of the PAC expansion I/O in a C# language environment.

The following demos can be found by downloading the latest version from ICP DAS web site.

<http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/demo/ypac/c%23/io/>

Folder	Demo	Explanation
Local	find_io	Shows how to retrieve the module name and type which plugged in the XP-8000-CE6.
	8k_di	Shows how to read the DI values of DI module. This demo program is used by 8K series DI modules.
	8k_do	Shows how to write the DO values to DO module. This demo program is used by 8K series DO modules.
	8k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 8K series DIO modules.
	87k_basic	Shows how to send/receive a command/response application. This demo program is used by 87K series modules.
	87K_demo	Shows how use uart API and the IO modules located as slots. This demo program is used by 87K series modules.
	87k_ai	Shows how to read the AI values of AI module. This demo program is used by 87K series AI modules.
	87k_ao	Shows how to write the AO values to AO module. This demo program is used by 87K series AO modules.
	87k_di	Shows how to read the DI values of DI module. This demo program is used by 87K series DI modules.
Local	87k_do	Shows how to write the DO values to DO module. This demo program is used by 87K series DO modules.
	87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 87K series DIO modules.
Remote	7k87k_basic	Shows how to send/receive a command/response application. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_ai	Shows how to read the AI values of AI module. This demo program is used by 7K or 87K series

Folder	Demo	Explanation
		AI modules which connected through a COM port.
	7k87k_ao	Shows how to write the AO values to AO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_di	Shows how to read the DI values of DI module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_do	Shows how to write the DO values to DO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.

6.2.3. Visual C++ Demos for PAC Expansion I/O

The PAC SDK includes the following demos that demonstrate the use of the PAC expansion I/O in a C# language environment.

The following demos can be found by downloading the latest version from ICP DAS web site.

<http://ftp.icpdas.com/pub/cd/xp-8x3x-ce6/demo/ypac/vc2005/io/>

Folder	Demo	Explanation
Local	find_io	Shows how to retrieve the module name and type which plugged in the XP-8000-CE6.
	8k_di	Shows how to read the DI values of DI module. This demo program is used by 8K series DI modules.
	8k_do	Shows how to write the DO values to DO module. This demo program is used by 8K series DO modules.
	8k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 8K series DIO modules.
	87k_basic	Shows how to send/receive a command/response application. This demo program is used by 87K series modules.
	87K_demo	Shows how use uart API and the IO modules located as slots. This demo program is used by 87K series modules.
	87k_ai	Shows how to read the AI values of AI module. This demo program is used by 87K series AI modules.
	87k_ao	Shows how to write the AO values to AO module. This demo program is used by 87K series AO modules.
	87k_di	Shows how to read the DI values of DI module. This demo program is used by 87K series DI modules.
Local	87k_do	Shows how to write the DO values to DO module. This demo program is used by 87K series DO modules.
	87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 87K series DIO modules.
Remote	7k87k_basic	Shows how to send/receive a command/response application. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_ai	Shows how to read the AI values of AI module. This demo program is used by 7K or 87K series

Folder	Demo	Explanation
		AI modules which connected through a COM port.
	7k87k_ao	Shows how to write the AO values to AO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_di	Shows how to read the DI values of DI module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_do	Shows how to write the DO values to DO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.
	7k87k_dio	Shows how to read the DI and the DO values of the DIO module. This demo program is used by 7K or 87K series AI modules which connected through a COM port.

7. Recovery and Restore

This chapter provides information of the XP-8000-CE6 restore and recovery, and a guided tour that describes the steps needed to restore and recovery the XP-8000-CE6.

The rescue CF card or USB disk that can be used to not only boot the XP-8000-CE6 when the OS fails to load, but also recover files.


The recovery file of the rescue CF card or USB disk can be found separately on the CD that was provided with the package or by downloading the latest version from ICP DAS web site.

<https://www.icpdas.com/en/download/show.php?num=2801>

7.1. Recovering the XP-8000-CE6

If the XP-8000-CE6 crashes and won't start up, you can use the rescue CF card or USB disk to start up the XP-8000-CE6 and then fix the problem that caused the crash.

Step 1: Plug the CF card in CF slot or USB Disk in USB Port and turn the rotary switch in position 0




Step 2: Reboot the XP-8000, press Delete key to enter the BIOS setup utility

Step 3: On the Advanced menu, select USB Configuration and then press Enter key

BIOS SETUP UTILITY					
Main	Advanced	PCIPnP	Boot	Security	Exit
Advanced Settings WARNINGS: Setting wrong values in below sections may cause system to malfunction. ▶ IDE Configuration ▶ Serial/Parallel Port Configuration ▶ Remote Access Configuration ▶ USB Configuration ▶ Power Management Configuration ▶ Smbios Configuration					Configure the USB support


Step 4: Set Legacy USB Support as Enabled, it means enable the USB legacy support



Step 5: Select F10 key and select OK to exit the BIOS Setup Utility and reboot the XP-8000-CE6

Step 6: Reboot the XP-8000-CE6, press F10 key to enter the Boot menu

Step 7: On the Boot menu, if you insert a CF card, select HDD: PM-InnoDisk Corp. iCF 1ME 16. If you insert a USB disk, select USB: (your USB disk), and then press the Enter key.



Step 8: Enter 1, (1) create XPAC_CE default partition

Wait a while until we enter the XP-8000-CE6 Rescue Utility again.

```
=====
==                               ==
Main Menu
=====

**   the following 3 steps help you   **
**   restore default XPAC_CE OS.     **

(1) Step 1: create XPAC_CE default partition.
(2) Step 2: format and restore XPAC_CE to factory default OS.
(3) Step 3: reboot

(6) Display directory information on built-in flash

Please enter your choice: 1
```

Step 9: Enter 2, (2) format and restore XPAC_CE to factory default OS.

Wait a while until we enter the XP-8000-CE6 Rescue Utility again.

```
=====
==                               ==
Main Menu
=====


**   the following 3 steps help you   **
**   restore default XPAC_CE OS.     **

(1) Step 1: create XPAC_CE default partition.
(2) Step 2: format and restore XPAC_CE to factory default OS.
(3) Step 3: reboot

(6) Display directory information on built-in flash

Please enter your choice: 2
```

Step 10: Enter 3, (3) reboot



Step 13: Repeat step 2 to step 6 to set Legacy USB Support as Disabled

BIOS SETUP UTILITY					
Main	Advanced	PCIPnP	Boot	Security	Exit
USB Configuration Module Version – x.x.x-xx.x USB Devices Enabled : 1 1 Keyboard USB Support [Enabled] Legacy USB Support [Disabled] Reset USB HC Support [Disabled] Support USB Device Wakeup [Disabled]					Enables support for legacy USB. Auto option disables legacy support if no USB devices are connected.

Step 14: The XP-8000-CE6 has been recovered

7.2. Restoring the Rescue CF Card or USB Disk

The rescue CF card or USB disk is rescue equipment that allows you to perform some maintenance tasks on your system in case of failure.

Once the rescue CF card are partitioned or formatted, you must restore the rescue CF card or USB disk.

Requirements

For restoring the Rescue CF card or USB Disk, you should prepare Ghost 11 or later, which you could obtain by contacting Symantec (<http://www.symantec.com>)

Here are step by step instructions on how to restore the rescue CF card. In this demonstration, we will use Symantec Norton Ghost32 V.11.0 (The Symantec Norton Ghost V.11 or above version are recommend).

Step 1: Get the latest version of rescue ghost file, rescue.gho


The latest version of rescue.gho file can be found by downloading the latest version from ICP DAS web site.

https://www.icpdas.com/web/product/download/pac/wince/xp-8x31-ce6/software/os/R3600_Rescue_v1800_20220620.GHO


Step 2: Start the Symantec Norton Ghost32 V.11, and then click OK




Step 3: Click Function Menu, point to Local, point to Disk, and then click From Image




Step 4: Select the rescue ghost file that you saved, and then click Open




Step 5: Select the destination to CF card or USB disk and click then OK



Step 6: Recovery the rescue ghost file into CF card or USB Disk and then click OK



Step 7: The rescue CF card or USB disk has been done



8. XP-8000-CE6 Updates

This chapter provides a guided tour that demonstrates the steps needed to update the XP-8000-CE6 OS and SDKs.

ICP DAS will continue to add additional features to XP-8000-CE6 SDK and OS in the future, so we advise you to periodically check the ICP DAS web site for the latest updates.

The file location of the OS and SDK

Both the files of OS updates and SDK updates can be found by downloading the latest version from Download Center.

<https://www.icpdas.com/en/download/index.php?model=XP-8000-CE6%20Series>

XP-8000-CE6 Series

Standard PAC with x86 CPU and WinCE 6.0

Features

- x86 CPU, 1.0 GHz, dual-core
- Windows CE 6.0
- Hard Real-Time Capability
- Rich software support
- Various Memory and Storage

OS Images

FILE NAME	DESCRIPTION	MODEL	LAST UPDATE
XP-8000-CE6	OS Image	XP-8000-CE6 Series	2025-12-03

SDK

FILE NAME	DESCRIPTION	MODEL	LAST UPDATE
WinCE6.0 PACs	SDK and Demo Samples	XP-8000-CE6 Series	2025-12-03

8.1. OS updates

OS updates are part of the XP-8000-CE6 updates services to provide additional and more efficient features and functionality for XP-8000-CE6 operating system.

There are two ways to update the OS:


1. Update from file (Please refer to section 8.1.1)

(We recommend that you use this one for more quicker and easier to update)

2. Update from rescue CF card or USB disk (Please refer to section 8.1.2)

8.1.1. OS Updates from file

The OS update file can be obtained via the network. Before updating the OS, make sure the XP-8000-CE6 is connected to the network.



Step 1: Get the latest version of the OS image file, NK.bin

The latest version of the OS image file, NK.bin, can be found from ICP DAS web site.


<https://www.icpdas.com/en/download/show.php?num=2801>

Step 2: Replace an old one OS with a new one

The OS image, NB.bin are pre-installed on the \System_Disk


Step 3: Reboot the XP-8000-CE6, the OS image has been updated completely

Run the XPAC Utility, click Reboot from the File menu for changes to take effect.



Step 4: Check the OS version

Run the XPAC Utility, and then select the Device Information tab to check the current OS version.



8.1.2. OS Updates using the Rescue CF Card or USB disk

The XP-8000-CE6 can be reinstalled with the XP-8000-CE6 Rescue Utility. Before reinstalling the XP-8000-CE6, make sure the necessary updating files have been are available on your CF card or USB disk.

For more information on how to reinstall the XP-8000-CE6, please refer to section 7.1. Recovering the XP-8000-CE6

8.2. SDK Updates

SDK update is a part of the XP-8000-CE6 update services to provide additional and more efficient features and functionality for XP-8000-CE6 operating system.

8.2.1. SDK Updates for VB.NET or C#

The SDK can be updated by replacing the PACNET.dll file.

Step 1: Get the latest version of the PACNET.dll file

The latest version of the PACNET.dll file can be obtained from ICP DAS web site.

https://www.icpdas.com/web/product/download/pac/wince/software/sdk/ce6/PACNET_CE6_x86.zip


Step 2: Copy the latest version of PACNet.dll file to PC and XP-8000-CE6

The PACNET.dll file on PC can be placed anywhere only the solution can reference it.

The PACNET.dll file on XP-8000-CE6 is located at the same directory as the .exe file.


Step 3: Reboot the XP-8000-CE6, the SDK has been updated completely

Run the XPAC Utility, click Reboot from the File menu for changes to take effect.



Step 4: Check the SDK version

Run the XPAC Utility, and then select the Device Information tab to check the current SDK version.



8.2.2. SDK Updates for VB.NET or Visual C++

The SDK can be updated by replacing the PAC SDK files.

Step 1: Get the latest version of the VC++ components

The latest version of the VC++ components can be obtained from:

https://www.icpdas.com/web/product/download/pac/wince/software/sdk/ce6/PACSDK_CE6_x86.zip

Step 2: Copy the latest version of header files and libraries to PC

The header files are located at:

C:\Program Files\Windows CE Tools\wce600\XPacSDK_CE\Include\X86\

The libraries are located at:

C:\Program Files\Windows CE Tools\wce600\XPacSDK_CE\Lib\x86\


Step 3: Copy the latest version of DLL files to XP-8000-CE6

The DLL files are located at:

\System_Disk\ICPDAS\System


Step 4: Reboot the XP-8000-CE6, the SDK has been updated completely

Run the XPAC Utility, click Reboot from the File menu for changes to take effect.



Step 5: Check the SDK version

Run the XPAC Utility, and then select the Device Information tab to check the current SDK version.




9. Application of RS-485 Network

The RS-485 length can be up to 4000 ft or 1.2 km over a single set of twisted-pair cables, if the RS-485 network is over 4000 ft or 1.2Km, the RS-485 repeater must be added to extend the RS-485 network.


9.1. Basic RS-485 Network

The basic component of the RS-485 network consist of a Master Controller (or using a PC as a host controller), and some RS-485 devices.




9.2. Daisy Chain RS-485 Network

All RS-485 devices are wired directly to the main network, If the network is up to 1.2 km, it will need a repeater (7510 series) to extend the network length.




9.3. Star Type RS-485 Network

There are branches along the main network. In this case, it is better to have a repeater to isolate or filter the noise that is made by devices.




There is a better choice to use 7513 as a RS-485 hub on start type network.



9.4. Random RS-485 Network

There are branches along the main wire. In this case, it is better to have a repeater to isolate or filter the noise that is made by devices.




9.5. Master/Slave Settings

The RS-485 network based on master-slave architecture consists of a single master device and one or more slave devices.


The XPAC provides two RS-485 communication interfaces based on the master-slave system architecture, all of which have a pull-high/pull-low resistor, user can set it to master or slave for implementing an RS-485 multi-drop network.

One of the RS-485 communications, COM3, its pull-high/pull-low resistor located on power board, the other, COM4, located on the right side and its pull-high/pull-low resistor located on the bottom of the right side, as shown below.




9.5.1. XPAC as a Master (Default)

When one of XPAC is set to master, then all the other devices on the same network must be slave mode. If the network is up to 1.2 KM, it will need a repeater (7510 series) to extend the network length.



When XPAC as a master using COM3 communication interface, the pull-high/pull-low resistor located on the power board must adjust to enable as shown below.




When XPAC as a master using COM4 communication interface, the pull-high/pull-low resistor located on the power board must adjust to enable as shown below.




9.5.2. XPAC as a Slave

For most of application, when using one 7520 series as RS-232/485 converter, its pull-high/pull-low resistors are set to enabled. Then the XP-8000-CE6 and all the other devices on this network must be slave mode (the pull-high/pull-low resistors must be disabled).

If there are repeaters on the RS-485 network, there will be pull-high/pull-low resistors on both sides of the repeaters (I-7510)



When XPAC as a master using COM3 communication interface, the pull-high/pull-low resistor located on the power board must adjust to enable as shown below.



When XPAC as a master using COM4 communication interface, the pull-high/pull-low resistor located on the power board must adjust to enable as shown below.




Tips – How to

This chapter provides tips and a guided tour on using and maintaining the XP-8000.

A. How to Use the Printer

XP-8000-CE6 have ability to access the printer, the printer can be connected via an Ethernet or a USB.



Tips & Warnings



XP-8000-CE6 only supports HP Laser Jet Printers with PCL6 driver. The following printer support is released by HP:

- HP LaserJet 4000 series/HP LaserJet 4100 series
- HP LaserJet 2100 series/HP LaserJet 2200 series
- HP LaserJet 1200
- HP LaserJet 3200/HP LaserJet 3300
- HP LaserJet 4200 series/HP LaserJet 4300 series
- HP LaserJet 5000 series/HP LaserJet 5100 series
- HP LaserJet 8000 series
- HP LaserJet 9000 series printers


If you need the latest support of HP PCL6 printer, you can refer to following link

<http://h20000.www2.hp.com/bizsupport/TechSupport/Document.jsp?objectID=bpl04568>


A.1. How to Use a Network Printer

Here are step by step instructions on how to use a shared printer.

Step 1: On PC side, check the name of the PC and the shared printer



Step 2: On XP-8000-CE6 side, run the Notepad, and then open a WordPad format file



Step 3: Set up the printer

1. Printer: PCL Laser
2. Port: Network
3. Net Path: \\ServerName\\PrinterName


The "ServerName" is the name or IP of the PC.

The "PrinterName" is the name of share printer of the PC.

4. Paper Size: Select the paper size




Test !!!



A.2. How to Use a USB printer

Here are step by step instructions on how to use a USB printer via a USB port.

Step 1: Run the Notepad, and then open a WordPad format file




Step 2: Set up the printer

1. Printer: Hewlett-Packard LaserJet
2. Port: LPT1
3. Paper Size: Select the paper size



Test !!!



B. How to Online Debug the XP-8000-CE6 Program

Here are step by step instructions on how to online debug the XP-8000-CE6 program.

Tips & Warnings



Before starting online debug the XP-8000-CE6 program, make sure that the XP-8000-CE6 SDK has been installed correctly.


For more information on how to install the XP-8000-CE6 SDK, please refer to 4.1.2. Installing the XP-8000-CE6 SDK.

Step 1: Copy the following files to the \System_Disk\icpdas\system on the XP-8000


By default, these files are located on the development computer at C:\Program Files\Common Files\Microsoft Shared\CoreCon\1.0\Target\wce400\<CPU>.

- clientshutdown.exe
- CMAccept.exe
- ConmanClient2.exe
- eDbgTL.dll
- TcpConnectionA.dll

Step 2: Run the ConmanClient2.exe and then CMAccept.exe on the XP-8000-CE6




Step 3: On the Tools menu, click the Options




Step 4: In the left pane, expand Device Tools node and select Devices


Step 5: In the Show devices for platform:, select XPacSDK_CE and then click Properties





Step 6: Click the Configure...




Step 7: Select the Use specific IP address:, and then type the IP address of XP-8000-CE6




Step 8: Click the OK, and then click OK to end the dialog




Step 9: On the Tools menu, click the Connect to Device...



Step 10: Click the Connect



Step 11: Wait for the connection to be established




Tips & Warnings



If the connection fails shown as follow, return to step 10 to do the action



Open the command prompt, run the
“ConmanClient2.exe/transport:tcpconnectiona.dll/property:port=5000/id:Con
on” at: \System_Disk\ICPDAS\System, and then run the “CMAccept.exe”




C. How to Automatically Synchronize XP-8000-CE6 Clock with an Internet Time Server

The clock on the XP-8000-CE6 can be synchronized with an internet time server. This means that the clock is updated to match the clock on the time server, which can help ensure that the time on the XP-8000-CE6 is accurate. Here are step by step instructions on how to synchronize the clock on the XP-8000-CE6 with an Internet time server.

Step 1: Run the XPAC Utility




Step 2: On the General tab, press Configure button




Step 3: Select the domain name from the Server drop-down list, and then enter a value in the Autoupdate Frequency field

Step 4: Check the Automatically synchronize with an internet time server check box




Step 5: On the File menu, click Reboot



Step 6: The XP-8000-CE6 will automatically synchronize with an internet time server regularly

Step 7: Click the Update Now button to synchronize XP-8000-CE6 clock immediately



D. How to Control the User Account Control in XP-8000-CE6

User Account Control is a security feature that helps prevent unauthorized system changes to the XP-8000-CE6.


D.1. How to Create a User Account

Here are step by step instructions on how to add a user account.


Step 1: Run the XPAC Utility




Step 2: On the Login tab of the Network tab, click Login tab, type the User Name and Password, and then click Add button



Step 3: The user has been added to the allowed under the remote login and included in the following list




Step 4: On the File menu, click Reboot for changes to take effect




D.2. How to Telnet to Remote Login the XP-8000-CE6 from PC

Here are step by step instructions on how to use telnet to remote login the XP-8000-CE6 from PC.


Step 1: On the PC, open a MS-DOS command prompt




Step 2: At the command prompt, type "telnet (IP address)"



Step 3: The connection has been set up, and then type the name and password



Step 4: The remote login has been completed




D.3. How to Remove a User Account from the Login List

Here are step by step instructions on how to remote the user from the login list.


Step 1: Run the XPAC Utility



Step 2: On the Login tab of the Network tab, click Login tab, click a user from the list which you want to remove, and the user will display in the field, and then press Delete to delete the user from the login list



Step 3: On the File menu, click Reboot for changes to take effect



E. How to use PACSDK library to program the XP-8000-CE6

E.1. How to Read the XPAC Mode with PACSDK library

The rotary switch is used to set the operating mode.



During normal operation, the position of the rotary switch has no effects on XP-8000-CE6. You can use PACSDK API to read back the value of the rotary switch.

```
int pac_GetRotaryID();
```

The returning value of `pac_GetRotaryID()` is what the arrow points to.

E.2. How to Read the Module ID with XPAC API

The DIP switch can be used to set the Module ID to a number from 0 to 255. Do not use Module ID 0 for communication.

During normal operation, the positions of the DIP switches have no effects on XP-8000-CE6. You can use PACSDK API to read back the value of the DIP switches.

```
int pac_GetDIPSwitch();
```


Below is the figure of DIP switches similar to that of XP-8000-CE6.

The first DIP switch is the LSB and the 8th DIP switch is the MSB.

If the DIP switch slides up to the “ON” side, it represents 1.

If the DIP switch slides down to the number side, it represents 0.

In this way, the eight-bit DIP switches can be represented by 0 ~ 255.




E.3. How to Use the Multi-IO Module with XPAC API

The Multi-IO Modules tab provides function to check the driver of multi-IO modules, such as 8114, 8144, 8142, and 8112.

For more information about expansion RS-232/RS-422/RS-485 communication module that are compatible with the XP-8000-CE6, please refer to


[https://www.icpdas.com/en/product/guide+Remote I/O Module and Unit+PAC I/O Modules+I-8K I-87K Series \(High Profile\)#481](https://www.icpdas.com/en/product/guide+Remote+I/O+Module+and+Unit+PAC+I/O+Modules+I-8K+I-87K+Series+(High+Profile)#481)

1. Insert the multi-IO module into XP-8000-CE6
2. Run the XPAC Utility
3. On the Multi-IO Modules tab, check the driver of the I/O modules



4. Program the multi-IO module

Opening 8144 in Slot 1



Code Snippets

```
{  
    BOOL ret;  
    HANDLE hOpen;  
    char buf[4096];  
  
    hOpen = uart_Open("MSA1");  
    ret = uart_SendCmd(hOpen, "$01M", buf);  
    uart_Close(hPort);  
}
```

For more information about expansion RS-232/RS-422/RS-485 communication module that are compatible with the XP-8000-CE6, please refer to

[https://www.icpdas.com/en/product/guide+Remote I O Module and Unit+PAC I O Modules+I-8K I-87K Series \(High Profile\)#481](https://www.icpdas.com/en/product/guide+Remote+I+O+Module+and+Unit+PAC+I+O+Modules+I-8K+I-87K+Series+(High+Profile)#481)

F. How to update software from XP-8x4x-CE6 or XP-8000-Atom-CE6 to XP-8x3x-CE6

The CPU type of XP-8x4x-CE6 and XP-8000-Atom-CE6 is x86-based and the OS is also Windows CE6.0, so all software are compatible. All old programs and applications on XP-8x4x-CE6 and XP-8000-Atom-CE6 can run smoothly on XP-8x3x-CE6 without any modification and re-compiling. Upgrading applications only just copy and play from XP-8x4x-CE6 or XP-8000-Atom-CE6 to XP-8x3x-CE6.

The software compatibility is listed as following:

Software compatibility with XP-8x3x-CE6

Compatibility Comparison O: Compatible, X: Incompatible	
Items	Compatibility
OS image	X
Rescue Disk	X
VC/C#/VB.net programs	O
XPacSDK_CE6 SDK (DLL file)	X
PACSDK (DLL file)	O (Since V4.4.0.1 and later)
All DCON 8K series library	O
XPAC utility	O (Since V1.2.7.3 and later)
NAPOPC_CE6	O
Tools on System_Disk	O

Compatibility Comparison O: Work, X: Doesn't Work			
API Functions	XP-8x4x-CE6	XP-8000-Atom-CE6	XP-8x3x-CE6
pac_EnableLEDs	X	O	O
The others	O	O	O

Note: The version of PACSDK must be V4.4.0.1 or later

G. How to Change the Battery

The XPAC is equipped with a **BR2032** battery by default. A **CR2032** battery is also supported and can be used as a replacement.


Battery Comparison

Both BR2032 and CR2032 batteries are supported. The following table summarizes the key differences between the two battery types.


Feature	BR2032	CR2032
Cathode Material	Lithium Poly-carbon Monofluoride (Li/(CF) _n)	Lithium Manganese Dioxide (Li/MnO ₂)
Operating Temperature	Approx. -30 °C to +80 °C	Approx. -20 °C to +60 °C
Discharge Characteristics	Voltage remains relatively stable during most of the discharge period.	Voltage gradually decreases during discharge.
Self-Discharge Rate	Extremely low (<1% per year)	Low (~1 – 2% per year)
Typical Shelf Life	10 – 15 years	8 – 10 years

Battery Replacement Procedure


Step 1: Pull up the locking tabs on both sides, and then remove the CPU unit from the main unit



Step 2: Remove the CPU board from the CPU unit




Step 3: Use the screwdriver to press the battery release tab and release the battery from the holder



Step 4: Use the screwdriver to remove the old battery from the battery holder

Step 5: Insert a BR2032 or CR2032 battery into the battery holder

If necessary, use the screwdriver to gently press the battery into place



Step 6: Reinstall the CPU board into the CPU unit, and then mount the CPU unit back onto the main unit

H. I-8K and I-87K Modules

I-8K and I-87K modules provide the option to expand the local I/O to 1, 3, or 7 slots and the bus type for the modules can be either parallel (high profile I-8K series) or serial (high profile I-87K series).

The differences between the two module types is as follows.

Item	I-8K Series	I-87K Series
Microprocessor	No	Yes (8051)
Communication Interface	Parallel Bus	Serial Bus
Communication Speed	Fast	Slow
Latched DI Function	No	Yes
Counter Input (for digital input modules)	No	Yes (100 Hz)
Power-on Value	No	Yes
Safe Value	No	Yes
Programmable Slew-Rate for AO modules	No	Yes

I. Revision History

This chapter provides revision history information to this document.

The table below shows the revision history.

Revision	Date	Description
1.0.0	October 2016	Initial issue
1.0.1	March 2017	Modified the power specification in section 1.2. Specification
1.0.2	March 2018	Added the information about XP-8031-CE6 in Chapter 1. Introduction
1.0.3	September 2021	1. Modified the information about Recovering the XP-8000-CE6 in section 7.1 Recovering the XP-8000-CE6 2. Added the information about how to change the battery in Appendix G. How to Change the Battery
1.0.4	September 2021	Modified the information about Recovering the XP-8000-CE6 in section 7.1 Recovering the XP-8000-CE6
1.0.5	December 2023	Added the tips and warnings information about the CF card supported in section 1.3. Overview
1.0.6	December 2025	Added the information about the usb disk supported in chapter 7. Recovery and Restore